

D6 ADJUSTABLE STOP

NOTES:

- 1) REMOVE HEX NUT & LOCKWASHER*
- 2) ROTATE ADJUSTABLE STOP
TO DESIRED POSITION*
- 3) REPLACE LOCKWASHER AND HEX NUT*

